

Take the guesswork out of getting a precise fit

,'GC.'

FIT CHECKER™ ADVANCED WHITE

The ideal colour for acrylic and metal

- FIT CHECKER™ ADVANCED WHITE offers ideal consistency and high wettability for easy flow onto dentures and saliva-coated oral tissues.
- Perfect for all kinds of prosthetic work, such as dentures and metal-based crowns and bridges.
- FIT CHECKER™ ADVANCED WHITE is now even easier to use in automix delivery.









Ideal for metal crowns and bridges

FIT CHECKER™ **ADVANCED**

Apply and seat

A Vinyl PolyEther Silicone for simple and precise checking and adjustment of all prosthetic work.

Snap set

Sufficient working time and rapid setting time (w/t 1 minute, s/t 1 minute in mouth).

Clear and precise visualisation

A perfect colour gradation for immediate visualisation of occlusal contacts and poorly fitting areas.

FIT CHECKER™ ADVANCED BLUE


The ideal colour for all ceramic work – adjust the right spots and take the guesswork out of getting a precise fit

- Perfect for checking the fit for all kinds of ceramic work, especially resin, ceramic and zirconia.
- Can be used for bite registration and evaluation of occlusal contacts, as well as checking the fit of splints.

Finally, it's possible to make certain of a perfect fit for indirect ceramic restorations, avoiding marginal gaps and major occlusal adjustments after cementation.







Seat

Check and adjust

Bite registration

No mess during adjustments

The set material does not get caught by the bur while relieving pressure spots.

Easy to peel off

The Vinyl PolyEther Silicone peels off easily for a clean and fast procedure.





FIT CHECKER™ ADVANCED WHITE Tube Pack

1x 42ml base

1x 42ml catalyst

1x 3g retarder

1x mixing pad



FIT CHECKER™ ADVANCED WHITE Cartridge Pack

2x 48ml cartridge

3x mixing tip IIS

3x mixing tip IISS



FIT CHECKER™ ADVANCED BLUE Cartridge Pack

2x 48ml cartridge 3x mixing tip IIS 3x mixing tip IISS

Technique tip

FIT CHECKER™ ADVANCED contains A-silicone components. Contact with latex gloves, unpolymerised resin and eugenol-containing materials may hinder its setting reaction. Before cementing restorations, clean with alcohol to remove any residual silicone oil as this could interfere with the cementation process.

Copyright © 2014

T: +61 2 9316 4499 **F:** +61 2 9316 4196

www.gcasia.info

