


# everX Flow™ Technique Guide


GC

SHORT-FIBRE REINFORCED FLOWABLE COMPOSITE FOR DENTIN REPLACEMENT

## Direct restorations




Prepare cavity.



Bond and light-cure.



Place everX Flow; leave sufficient space for the overlaying composite.



Light-cure.



Occlusally cover with conventional restorative composite.

## Class II and large cavities



Place everX Flow; leave sufficient space for the overlaying composite.



Light-cure.



Occlusally cover with conventional restorative composite.



Build up missing walls using everX Flow or conventional restorative composite.



Light-cure.



Proceed with placing everX Flow in the cavity.



Light-cure.



Occlusally cover with conventional restorative composite.

### Irradiation Time and Effective Depth of Cure for everX Flow

|              | Irradiation time | 10 sec.<br>(High Power LED) | 20 sec.<br>(Halogen/ LED)<br>(>1200 mW/cm²) |
|--------------|------------------|-----------------------------|---|
| Shade        |                  |                             |   |
| Bulk shade   |                  | 5.5 mm                      |   |
| Dentin shade |                  | 2.0 mm                      |   |

The effective wavelength range of each dental curing unit must cover 450-480 nm.


 The Bulk shade can be placed using a bulk filling technique (up to 5.5 mm). The Dentin shade should be placed and light-cured in layers of 2.0 mm.

# everX Flow™ Technique Guide


GC

SHORT-FIBRE REINFORCED FLOWABLE COMPOSITE FOR DENTIN REPLACEMENT


## Core build-up




Prepare the surfaces to be bonded. Bond and light-cure.




Use everX Flow to build the core.



Light-cure.



Contour & finish the core.



Final core build-up preparation.

### Irradiation Time and Effective Depth of Cure for everX Flow

|              | Irradiation time | 10 sec.<br>(High Power LED) | 20 sec.<br>(Halogen/ LED)<br>(>1200 mW/cm²) |
|--------------|------------------|-----------------------------|---|
| Shade        |                  |                             |   |
| Bulk shade   |                  | 5.5 mm                      |   |
| Dentin shade |                  | 2.0 mm                      |   |

The effective wavelength range of each dental curing unit must cover 450-480 nm.

 The Bulk shade can be placed using a bulk filling technique (up to 5.5 mm). The Dentin shade should be placed and light-cured in layers of 2.0 mm.



The final indirect restoration should occlusally cover the everX Flow core build-up.



Prior to use, carefully read the instructions for use.



22  
PAP

20018552  
101253TZ